

# Floating-Point

## Objectives

After completing this lab, you will:

- Understand Floating-Point Number Representation (IEEE 754 Standard)
- Understand the MIPS Floating-Point Unit
- Write Programs using the MIPS Floating-Point Instructions
- Write functions that have floating-point parameters and return floating-point results

## Floating-Point Number Representation

Floating-point numbers have the following representation:

|          |                     |                     |
|----------|---------------------|---------------------|
| <b>S</b> | <b>E = Exponent</b> | <b>F = Fraction</b> |
|----------|---------------------|---------------------|

The Sign bit **S** is zero (positive) or one (negative).

The Exponent field **E** is 8 bits for single-precision and 11 bits for double-precision. The exponent field is biased. The **Bias** is 127 for single-precision and 1023 for double-precision.

The Fraction field **F** is 23 bits for single-precision and 52 bits for double-precision. Floating-point numbers are normalized (except when **E** is zero). There is an implicit **1**. (not stored) before the fraction **F**. Therefore, the value of a normalized floating-point number is:

$$\text{Value} = \pm (1.F)_2 \times 2^{E - \text{Bias}}$$

The MARS simulator has a floating-point representation tool that illustrates single-precision floating-point numbers. Go to **Tools** → **Floating Point Representation**, and open the window, shown in Figure 1.

Now use the tool to check the binary format and the decimal value of floating-point numbers.

For example, the decimal value of: **0 1000001 1011010000000000000000** is **6.75**.

Similarly, the 32-bit representation of: **-2.7531** is **1 10000000 01100000011001011001010**.




Figure 1: Floating-Point Representation tool supported by MARS

## MIPS Floating-Point Registers

The floating-point unit (called coprocessor 1) has 32 floating-point registers. These registers are numbered as **\$f0**, **\$f1**, ..., **\$f31**. Each register is 32 bits wide. Thus, each register can hold one single-precision floating-point number. How can we use these registers to store 64-bit double-precision floating-point numbers? The answer is that the 32 single-precision registers are grouped into 16 double-precision registers. The double-precision number is stored in an even-odd pair of registers, but we only refer to the even-numbered register. For example, when we store a double-precision number in **\$f0**, it is actually stored in registers **\$f0** and **\$f1**.

In addition, there are 8 condition flags, numbered from 0 to 7. These condition flags are used by floating-point compare and branch instructions. These are shown in Figure 2.

| Registers |            |                    | Coproc 1 | Coproc 0 |
|-----------|------------|--------------------|----------|----------|
| Name      | Float      | Double             |          |          |
| \$f0      | 0x00000000 | 0x0000000000000000 |          |          |
| \$f1      | 0x00000000 |                    |          |          |
| \$f2      | 0x00000000 | 0x0000000000000000 |          |          |
| \$f3      | 0x00000000 |                    |          |          |
| \$f4      | 0x00000000 | 0x0000000000000000 |          |          |
| \$f5      | 0x00000000 |                    |          |          |
| \$f6      | 0x00000000 | 0x0000000000000000 |          |          |
| \$f7      | 0x00000000 |                    |          |          |
| \$f8      | 0x00000000 | 0x0000000000000000 |          |          |
| \$f9      | 0x00000000 |                    |          |          |
| \$f10     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f11     | 0x00000000 |                    |          |          |
| \$f12     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f13     | 0x00000000 |                    |          |          |
| \$f14     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f15     | 0x00000000 |                    |          |          |
| \$f16     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f17     | 0x00000000 |                    |          |          |
| \$f18     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f19     | 0x00000000 |                    |          |          |
| \$f20     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f21     | 0x00000000 |                    |          |          |
| \$f22     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f23     | 0x00000000 |                    |          |          |
| \$f24     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f25     | 0x00000000 |                    |          |          |
| \$f26     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f27     | 0x00000000 |                    |          |          |
| \$f28     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f29     | 0x00000000 |                    |          |          |
| \$f30     | 0x00000000 | 0x0000000000000000 |          |          |
| \$f31     | 0x00000000 |                    |          |          |

| Condition Flags            |                            |                            |                            |
|----------------------------|----------------------------|----------------------------|----------------------------|
| <input type="checkbox"/> 0 | <input type="checkbox"/> 1 | <input type="checkbox"/> 2 | <input type="checkbox"/> 3 |
| <input type="checkbox"/> 4 | <input type="checkbox"/> 5 | <input type="checkbox"/> 6 | <input type="checkbox"/> 7 |

Figure 2: MIPS Floating-Point Registers and Condition Flags

## MIPS Floating-Point Instructions

The FPU supports several instructions including floating-point load and store, floating-point arithmetic operations, floating-point data movement instructions, convert, and branch instructions. We start this section with the floating-point load and store instructions. These instructions load into or store a floating-point register. However, they use the same base-displacement addressing mode used with integer instructions. Notice that the base address register is an integer (not a floating-point) register.

| Instruction               | Example                  | Meaning  |
|---------------------------|--------------------------|--|
| <b>lwc1</b> or <b>l.s</b> | <b>lwc1 \$f1,0(\$sp)</b> | Load a word from memory to a single-precision floating-point register: <b>\$f1 = MEM[\$sp]</b> |
| <b>ldc1</b> or <b>l.d</b> | <b>ldc1 \$f2,8(\$t1)</b> | Load a double word from memory to a double-precision register: <b>\$f2 = MEM[\$t1+8]</b>       |

| Instruction        | Example                   | Meaning  |
|--------------------|---------------------------|--|
| <b>swc1 or s.s</b> | <b>swc1 \$f5,4(\$t2)</b>  | Store a single-precision floating-point register in memory: <b>MEM[\$t2+4] = \$f5</b>  |
| <b>sdcl or s.d</b> | <b>sdcl \$f6,16(\$t3)</b> | Store a double-precision floating-point register in memory: <b>MEM[\$t3+16] = \$f6</b> |

The floating-point arithmetic instructions are listed next. The **.s** extension is used for single-precision arithmetic instructions, while the **.d** is used for double-precision instructions.

| Instruction   | Example                     | Meaning                                      |
|---------------|-----------------------------|--|
| <b>add.s</b>  | <b>add.s \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 + \$f4 (single-precision)</b> |
| <b>add.d</b>  | <b>add.d \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 + \$f4 (double-precision)</b> |
| <b>sub.s</b>  | <b>sub.s \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 - \$f4 (single-precision)</b> |
| <b>sub.d</b>  | <b>sub.d \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 - \$f4 (double-precision)</b> |
| <b>mul.s</b>  | <b>mul.s \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 × \$f4 (single-precision)</b> |
| <b>mul.d</b>  | <b>mul.d \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 × \$f4 (double-precision)</b> |
| <b>div.s</b>  | <b>div.s \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 / \$f4 (single-precision)</b> |
| <b>div.d</b>  | <b>div.d \$f0,\$f2,\$f4</b> | <b>\$f0 = \$f2 / \$f4 (double-precision)</b> |
| <b>sqrt.s</b> | <b>sqrt.s \$f0, \$f2</b>    | <b>Square root (single-precision)</b>        |
| <b>sqrt.d</b> | <b>sqrt.d \$f0, \$f2</b>    | <b>Square root (double-precision)</b>        |
| <b>abs.s</b>  | <b>abs.s \$f0, \$f2</b>     | <b>Absolute value (single-precision)</b>     |
| <b>abs.d</b>  | <b>abs.d \$f0, \$f2</b>     | <b>Absolute value (double-precision)</b>     |
| <b>neg.s</b>  | <b>neg.s \$f0, \$f2</b>     | <b>Negative value (single-precision)</b>     |
| <b>neg.d</b>  | <b>neg.d \$f0, \$f2</b>     | <b>Negative value (double-precision)</b>     |

The data movement instructions move data between general-purpose and floating-point registers, or between floating-point registers.

| Instruction  | Example                 | Meaning  |
|--------------|-------------------------|--|
| <b>mfc1</b>  | <b>mfc1 \$t0, \$f2</b>  | Move data from a floating-point register to a general-purpose register.                            |
| <b>mtc1</b>  | <b>mtc1 \$t0, \$f2</b>  | Move data from a general-purpose register to a floating-point register.                            |
| <b>mov.s</b> | <b>mov.s \$f0, \$f1</b> | Move single-precision data between two floating-point registers.                                   |
| <b>mov.d</b> | <b>mov.d \$f0, \$f2</b> | Move double-precision data between two floating-point registers (move even-odd pair of registers). |

The convert instructions convert the format of data in floating-point registers. Three data formats are supported: **.s** = single-precision float, **.d** = double-precision, and **.w** = integer word.

| Instruction      | Example                    | Meaning  |
|------------------|----------------------------|--|
| <b>cvt.s.w</b>   | <b>cvt.s.w \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from word to single-precision        |
| <b>cvt.s.d</b>   | <b>cvt.s.d \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from double to single-precision      |
| <b>cvt.d.w</b>   | <b>cvt.d.w \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from word to double-precision        |
| <b>cvt.d.s</b>   | <b>cvt.d.s \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from single to double-precision      |
| <b>cvt.w.s</b>   | <b>cvt.w.s \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from single-precision to word        |
| <b>cvt.w.d</b>   | <b>cvt.w.d \$f0,\$f2</b>   | <b>\$f0</b> = convert <b>\$f2</b> from double-precision to word        |
| <b>ceil.w.s</b>  | <b>ceil.w.s \$f0,\$f2</b>  | <b>\$f0</b> = Integer ceiling of single-precision float in <b>\$f2</b> |
| <b>ceil.w.d</b>  | <b>ceil.w.d \$f0,\$f2</b>  | <b>\$f0</b> = Integer ceiling of double-precision float in <b>\$f2</b> |
| <b>floor.w.s</b> | <b>floor.w.s \$f0,\$f2</b> | <b>\$f0</b> = Integer floor of single-precision float in <b>\$f2</b>   |
| <b>floor.w.d</b> | <b>floor.w.d \$f0,\$f2</b> | <b>\$f0</b> = Integer floor of double-precision float in <b>\$f2</b>   |
| <b>trunc.w.s</b> | <b>trunc.w.s \$f0,\$f2</b> | <b>\$f0</b> = Truncate single-precision float in <b>\$f2</b>           |
| <b>trunc.w.d</b> | <b>trunc.w.d \$f0,\$f2</b> | <b>\$f0</b> = Truncate double-precision float in <b>\$f2</b>           |

The floating-point compare instructions compare floating-point registers for equality, less than, and less than or equal. The FP compare instructions set the condition flags **0** to **7** to true (1) or false(0).

| Instruction   | Example                   | Meaning  |
|---------------|---------------------------|--|
| <b>c.eq.s</b> | <b>c.eq.s \$f2,\$f3</b>   | if ( <b>\$f2 == \$f3</b> ) set flag <b>0</b> to true else false      |
| <b>c.eq.d</b> | <b>c.eq.s 3,\$f4,\$f6</b> | Compare equal double-precision. Result in flag <b>3</b>              |
| <b>c.lt.s</b> | <b>c.eq.s 4,\$f5,\$f8</b> | if ( <b>\$f5 &lt; \$f8</b> ) set flag <b>4</b> to true else false    |
| <b>c.lt.d</b> | <b>c.lt.d 7,\$f4,\$f6</b> | Compare less-than double. Result in flag <b>7</b>                    |
| <b>c.le.s</b> | <b>c.le.s \$f10,\$f11</b> | if ( <b>\$f10 &lt;= \$f11</b> ) set flag <b>0</b> to true else false |
| <b>c.le.d</b> | <b>c.le.d \$f14,\$f16</b> | Compare less or equal double. Result in flag <b>0</b>                |

The floating-point branch instructions (**bc1t** and **bc1f**) branch to the target address based on the value of the specified condition flag (true or false).

| Instruction | Example              | Meaning  |
|-------------|----------------------|--|
| <b>bc1t</b> | <b>bc1t label</b>    | Branch to <b>label</b> if condition flag <b>0</b> is true  |
| <b>bc1t</b> | <b>bc1t 1, label</b> | Branch to <b>label</b> if condition flag <b>1</b> is true  |
| <b>bc1f</b> | <b>bc1f label</b>    | Branch to <b>label</b> if condition flag <b>0</b> is false |
| <b>bc1f</b> | <b>bc1f 4, label</b> | Branch to <b>label</b> if condition flag <b>4</b> is false |

## System Call Services for Floating-Point Numbers

The MARS tool provides the following **syscall** service numbers (passed in **\$v0**) to print and read single-precision and double-precision floating-point numbers:

| Service      | \$v0     | Arguments                      | Result                            |
|--------------|----------|--------------------------------|-----------------------------------|
| Print Float  | <b>2</b> | <b>\$f12</b> = float to print  |                                   |
| Print Double | <b>3</b> | <b>\$f12</b> = double to print |                                   |
| Read Float   | <b>6</b> |                                | Float is returned in <b>\$f0</b>  |
| Read Double  | <b>7</b> |                                | Double is returned in <b>\$f0</b> |

## MIPS Floating-Point Register Usage Convention

Compilers follow the MIPS register usage convention when translating functions and procedures into MIPS assembly-language code. The following table shows the MIPS software convention for floating-point registers. Not following the MIPS software usage convention can result in serious bugs when passing parameters, getting results, or using registers across function calls.

| Registers            | Usage  |
|----------------------|--|
| <b>\$f0 - \$f3</b>   | Floating-point procedure results   |
| <b>\$f4 - \$f11</b>  | Temporary floating-point registers, NOT preserved across procedure calls   |
| <b>\$f12 - \$f15</b> | Floating-point parameters, NOT preserved across procedure calls. Additional floating-point parameters should be pushed on the stack. |
| <b>\$f16 - \$f19</b> | More temporary registers, NOT preserved across procedure calls.  |
| <b>\$f20 - \$f31</b> | Saved floating-point registers. Should be preserved across procedure calls.  |

## In-Lab Tasks

1. Convert by hand the number **-123456789** into its 32-bit single-precision binary representation, and then use the floating-point representation tool presented in Section 9.2 to verify your answer. Show your work for a full mark.
2. Convert by hand the floating-point number **1 10010100 100110000011000000000000** (shown in binary) into its corresponding decimal value, and then use the floating-point representation tool presented in Section 9.2 to verify your answer. Show your work for a full mark.
3. Trace the following program by hand to determine the values of registers **\$f0** thru **\$f9**. Notice that **array1** and **array2** have the same elements, but in a different order. Comment on the sums of **array1** and **array2** elements computed in registers **\$f4** and **\$f9**, respectively. Now use the MARS tool to trace the execution of the program and verify your results. What conclusion can be made from this exercise?

```
.data
    array1: .float 5.6e+20, -5.6e+20, 1.2
    array2: .float 1.2, 5.6e+20, -5.6e+20
.text
    la      $t0, array1
    lwc1    $f0, 0($t0)
    lwc1    $f1, 4($t0)
    lwc1    $f2, 8($t0)
    add.s   $f3, $f0, $f1
    add.s   $f4, $f2, $f3
    la      $t1, array2
    lwc1    $f5, 0($t1)
    lwc1    $f6, 4($t1)
    lwc1    $f7, 8($t1)
    add.s   $f8, $f5, $f6
    add.s   $f9, $f7, $f8
```

4. Write an interactive program that inputs an integer **sum** and an integer **count**, computes, and displays the **average = (float) sum / (float) count** as a single-precision floating-point number. Hint: use the proper convert instruction to convert **sum** and **count** from integer word into single-precision float.